

GENERAL PRODUCT INFORMATION, INSTRUCTION FOR USE AND SAFETY INFORMATION

- Unique identification code of the product type:

Ardesia	Katia VXn Plus	Rosy Picture, Rosy Mirror
Claudia Elite	Katia VX Wide	Keira Verticale
Claudia	Kelly 5010	Keira Tandem Verticale
Claudia Square	Kelly 5010 Elite	Karin VX Verticale/Orizzontale
Claudia Wide	Samira	Karin VX Tandem Verticale/Orizzontale
Anna	Samira Wide	Alice 18 Verticale/Orizzontale
Naike Square	Federica	Alice 18 Tandem Verticale/Orizzontale
Naike ST	Fabiana	Alice 22 Verticale/Orizzontale
Lucy 18	Elen 18 Inox Lucido/Satinato	Alice 22 Tandem Verticale/Orizzontale
Lucy 18 Plus	Elen 18 Wide Inox Lucido	Alice 25 Verticale/Orizzontale
Lucy 18 Wide	Elen 22 Inox Lucido/Satinato	Alice 25 Tandem Verticale/Orizzontale
Lucy 25	Sandy Inox Lucido	Arianna Tandem
Lucy 25 Plus	Leila Inox Lucido	Doriana Verticale/Orizzontale
Gloria 18	Alessandra Inox Lucido/Satinato	Tamara Verticale/Orizzontale
Gloria 22	Laura Inox Lucido/Satinato	Tamara Tandem Verticale/Orizzontale
Gloria 22 Plus	Laura Ottone/Rame Antico	Lisa 22
Gloria 22 Cromato	Giada 18 Inox Lucido Verticale/Orizzontale	Lisa 22 Curvo
Gloria 22 Wide	Giada 18 Inox Satinato Verticale/Orizzontale	Lisa 25
Dory	Rosy Verticale/Orizzontale	Lisa 25 Curvo
Daria	Rosy Tandem Verticale/Orizzontale	
Katia VXn	Rosy Max	

- Declared uses, intended users and conditions of uses: Radiators for heating emission meant for permanent installation in heating systems of domestic buildings, supplied by a remote source of hot water or steam with temperature inferior to 110°C (EN 442-1-2 2014).
- Estimated average and minimum service life time for the declared use: 50 years and 30 years.
- Main materials used: Carbon steel or stainless steel with protective surface treatments or painted with ecological epoxy powders (Certificate DIN 55900-1,2).
- Manufacturer: CORDIVARI SRL, Zona Industriale Pagliare - 64020 Morro D'Oro (TE) - Tel: 085-80401 – E-mail: <mailto:info@cordivari.it> - Sito web: <http://www.cordivari.it/>
- Contact details: visit the Cordivari website, in the section <https://www.cordivari.it/contatti/>

- **Information for the installer:** The product purchased is subject to the general warranty provisions stated in the current official Cordivari catalogue. The warranty begins on the date of delivery and shall become null and void if the production lot information is tampered with and/or removed. The warranty shall be applicable after examination of the defects and their causes. The material to be replaced or repaired shall be delivered carriage paid to the dealer's warehouse. The obligation to honour the warranty shall be subject to the conditions and requirements listed below.

The radiator has not suffered damage during transport, handling or installation and has not been tampered with and/or repaired, unless expressly authorised, by third parties. The material has been stored in good conditions and protected against adverse weather conditions before installation. Installation of the product must be performed by qualified personnel and in accordance with these instructions and all national and local building and safety regulations. The radiator cannot be installed in circuits with an open tank system or domestic hot water circuits. Doing so shall immediately render the warranty null and void. Do not add harsh chemicals to the system water. Comply with the guideline values contained in standard UNI 8065 and any other local and national regulations on water treatment in heating systems. The radiator must operate within the maximum pressure and temperature values. Make sure that there are no traces of metal, calamine, grease or any other processing residue in the circuit. Prior to starting the system, flush it to remove residues from machining and/or any residues introduced during installation. During the start-up phase bleed the radiator using the special vent valve to let out any accumulated air or gas that prevents the system from working properly. If antifreeze is used, never use it pure. It must be diluted according to the manufacturer's instructions before being introduced into the circuit. If a corrosion inhibitor is used, it must be compatible with all materials present in the heating elements. The caps, fittings and hydraulic accessories used are those supplied by Cordivari srl. Do not install radiators in rooms containing chlorine vapours or corrosive fumes, e.g. swimming pools, saunas, hot tubes. **ATTENTION:** The mounting systems supplied, if any, are suitable for use on compact or hollow brick walls. For walls made of other materials, the installer is responsible for making sure appropriate mounting systems are used.

At the end of service life, this product must be disposed of at a collection centre to be recycled as it is not ordinary household waste. In case of replacement, it can be sent to your distributor or dealer. Managing the end of the service life of a product in this manner allows up to help protect the environment and save on natural resources.

- **Information for the user:** When it is time to turn on the heating system for the first time each winter make sure that there is no air in the system using the vent valve on the top of the manifold. Air in the system can interfere with the correct circulation of water resulting in the malfunctioning of the radiator. (loosen the vent valve, let out the air and then close the valve tightly) To clean painted radiators, use only a non-abrasive cloth dampened with water. To clean stainless steel radiators you can use a non-abrasive cloth dampened with water and methyl alcohol diluted 50%. Do not use detergents or harsh substances. Do not use any other acidic or basic solutions, chemical or other substances for industrial use, harsh or corrosive substances (bleach, ammonia, soda, etc.). Do not use abrasive sponges or cloths.
- **Warnings:** Risk of scalding: during normal operation radiator surfaces may get very hot.

Morro D'Oro, 07/01/2026

Sole Director

Ercole Cordivari

CORDIVARI S.r.l.
(L'Amministratore Unico)
Ercole Cordivari